Trouble shooting

HP40, HP50, HP60, HP100, Hydraulic press

Press unable to make pressure

Thank you for contacting us and for letting us participate in resolving the problem.

The most common problem if the press is unable to make pressure is that the pressure ball is not positioned correctly in its seat. Please follow the steps below to resolve the problem:

1. Tighten # 473 very hard by hand.
2. Hit the centre of # 473 hard with a hammer.
3. Loosen # 473 again.
4. Tighten # 473 hard by hand and try to operate the press.
5. If the press is still unable to make pressure then please try following the procedure from 1 to 4 again.
6. Should the problem not be solved then please contact Compac.